
CV Project

Real-Time Motion Detection and Facial Feature Tracking using YOLO, Haar Cascades, and Optical Flow

By Gurbaksh Lal (2023PCS2029)

Using requirement or tools for project:



Red: Required file to run the project here we use coco and yolo

Yellow: Programming files or main file of project

Green: Output CSV file capture frame movement time

Code:

Python->

```
import cv2
import pandas as pd
from datetime import datetime
import numpy as np
# Initialize the DataFrame with start and end time
df = pd.DataFrame(columns=["Start", "End"])
motionImage = []
time = []
stillmage = None
# Load pre-trained Haar cascades for face, eyes, and spectacles detection
face_cascade = cv2.CascadeClassifier(cv2.data.haarcascades + 'haarcascade_frontalface_default.xml')
eye_cascade = cv2.CascadeClassifier(cv2.data.haarcascades + 'haarcascade_eye.xml')
spectacles_cascade = cv2.CascadeClassifier(cv2.data.haarcascades +
'haarcascade_eye_tree_eyeglasses.xml')
# Load YOLO model for object detection
net = cv2.dnn.readNet(r'C:\Users\gurba\Project\Computer Vision Project\yolov3.weights',
r'C:\Users\gurba\Project\Computer Vision Project\yolov3.cfg')
with open(r'C:\Users\gurba\Project\Computer Vision Project\coco.names', 'r') as f:
  classes = [line.strip() for line in f.readlines()]
layer_names = net.getLayerNames()
output_layers = [layer_names[i - 1] for i in net.getUnconnectedOutLayers()]
# Parameters for Lucas-Kanade optical flow
```

```
lk_params = dict(winSize=(15, 15), maxLevel=2, criteria=(cv2.TERM_CRITERIA_EPS |
cv2.TERM CRITERIA COUNT, 10, 0.03))
# Create some random colors
color = np.random.randint(0, 255, (100, 3))
# Capturing video
video = cv2.VideoCapture(0)
video.set(cv2.CAP_PROP_FPS, 30) # Set frame rate to 30 FPS
# Background Subtractor
fgbg = cv2.createBackgroundSubtractorMOG2()
# Take first frame and find corners in it
ret, old_frame = video.read()
old_gray = cv2.cvtColor(old_frame, cv2.COLOR_BGR2GRAY)
p0 = cv2.goodFeaturesToTrack(old_gray, mask=None, maxCorners=100, qualityLevel=0.3,
minDistance=7, blockSize=7)
# Create a mask image for drawing purposes
mask = np.zeros_like(old_frame)
while True:
  # Start reading image from video
  check, frame = video.read()
  motion = 0
  # Apply background subtraction
  fgmask = fgbg.apply(frame)
  # Convert color image to gray_scale image
  gray = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
```

```
gray = cv2.GaussianBlur(gray, (5, 5), 0)
  if stillImage is None:
    stillImage = gray
    continue
  # Still Image and current image.
  diff_frame = cv2.absdiff(stillImage, gray)
  # Change the image to white if static background and current frame is greater than 25.
  thresh_frame = cv2.threshold(diff_frame, 25, 255, cv2.THRESH_BINARY)[1]
  thresh_frame = cv2.dilate(thresh_frame, None, iterations=2)
  # Finding contour and hierarchy from a moving object.
  contours, hierarchy = cv2.findContours(thresh_frame.copy(), cv2.RETR_EXTERNAL,
cv2.CHAIN_APPROX_SIMPLE)
  for contour in contours:
    if cv2.contourArea(contour) < 5000: # Lower the threshold
      continue
    motion = 1
    (x, y, w, h) = cv2.boundingRect(contour)
    cv2.rectangle(frame, (x, y), (x + w, y + h), (0, 255, 0), 1)
  # Append current status of motion
  motionImage.append(motion)
  motionImage = motionImage[-2:]
  # Append Start time of motion
  if len(motionImage) >= 2 and motionImage[-1] == 1 and motionImage[-2] == 0:
    time.append(datetime.now())
  # Append End time of motion
  if len(motionImage) >= 2 and motionImage[-1] == 0 and motionImage[-2] == 1:
    time.append(datetime.now())
  # Detect faces
```


```
faces = face_cascade.detectMultiScale(gray, 1.3, 5)
for (x, y, w, h) in faces:
  cv2.rectangle(frame, (x, y), (x + w, y + h), (255, 0, 0), 2)
  roi_gray = gray[y:y + h, x:x + w]
  roi_color = frame[y:y + h, x:x + w]
  # Detect eyes
  eyes = eye_cascade.detectMultiScale(roi_gray)
  for (ex, ey, ew, eh) in eyes:
    cv2.rectangle(roi_color, (ex, ey), (ex + ew, ey + eh), (0, 255, 0), 2)
  # Detect spectacles
  spectacles = spectacles_cascade.detectMultiScale(roi_gray)
  for (sx, sy, sw, sh) in spectacles:
    cv2.rectangle(roi_color, (sx, sy), (sx + sw, sy + sh), (0, 255, 255), 2)
# Calculate optical flow
frame_gray = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
# Ensure p0 is not None and has valid points
if p0 is not None and len(p0) > 0:
  p1, st, err = cv2.calcOpticalFlowPyrLK(old_gray, frame_gray, p0, None, **lk_params)
  if p1 is not None:
    good_new = p1[st == 1]
    good_old = p0[st == 1]
  else:
    good_new = np.array([])
    good_old = np.array([])
else:
  good_new = np.array([])
  good_old = np.array([])
```


```
# Ensure good_new is a numpy array
good_new = np.array(good_new)
# Now you can reshape it
p0 = good_new.reshape(-1, 1, 2)
# Draw the tracks
for i, (new, old) in enumerate(zip(good_new, good_old)):
  a, b = new.ravel().astype(int)
  c, d = old.ravel().astype(int)
  mask = cv2.line(mask, (a, b), (c, d), color[i].tolist(), 2)
  frame = cv2.circle(frame, (a, b), 5, color[i].tolist(), -1)
img = cv2.add(frame, mask)
# Display the frames
cv2.imshow("Frame", img)
cv2.imshow("Foreground Mask", fgmask)
cv2.imshow("Gray_Frame", gray)
cv2.imshow("Threshold Frame", thresh_frame)
cv2.imshow("Colored_Frame", frame)
key = cv2.waitKey(1)
# Press q to stop the process
if key == ord('q'):
  if motion == 1:
    time.append(datetime.now())
  break
```


```
# Now update the previous frame and previous points
  old_gray = frame_gray.copy()
  p0 = good_new.reshape(-1, 1, 2)
# Initialize an empty list to store the data
data = []
# Iterate through the time list in pairs
for i in range(0, len(time), 2):
  if pd.notna(time[i]) and pd.notna(time[i + 1]):
    # Append the pair to the data list
    data.append({"Start": time[i], "End": time[i + 1]})
# Convert the list to a DataFrame
df = pd.DataFrame(data)
# Print DataFrame to verify content
print(df)
# Creating a csv file in which time of movements will be saved
try:
  df.to_csv("FrameInMotion_time.csv")
  print("CSV file saved successfully.")
except Exception as e:
  print(f"Error saving CSV file: {e}")
video.release()
# close window
cv2.destroyAllWindows()
```


Output:


Video Type Output:











Program Output:

```
Start End
0 2024-11-16 14:15:13.476311 2024-11-16 14:15:13.711511
1 2024-11-16 14:15:13.855029 2024-11-16 14:15:14.089879
2 2024-11-16 14:15:14.152398 2024-11-16 14:15:14.248917
3 2024-11-16 14:15:14.313437 2024-11-16 14:15:14.556482
4 2024-11-16 14:15:14.635009 2024-11-16 14:15:14.795716
5 2024-11-16 14:15:16.949343 2024-11-16 14:15:16.982351
6 2024-11-16 14:15:24.138938 2024-11-16 14:15:46.915173
CSV file saved successfully.
```

Frame Motion CSV file output:

